

TC-W431

SERVICE MANUAL

*US Model
Mexican Model*

• TC-W431 is the CASSETTE DECK section in SEN-431CD.

This set is almost the same as model TC-W421 previously produced.
Therefore, see the service manual for the information which is not contained
in this service manual.

PAGE	TC-W431			
	<u>Ref.NO.</u>	<u>Part NO.</u>	<u>Description</u>	<u>Remarks</u>
15	2	X-4943-223-1	LID(B)ASSY, CASSETTE	
	3	X-4943-222-1	LID(A)ASSY, CASSETTE	
	5	X-3366-140-1	PANEL ASSY, FRONT	
	14	1-690-674-31	CORD(WITH CONNECTOR)	
	15	1-690-672-11	CORD(WITH CONNECTOR)(US:AV421/AV431)	
	*16	3-375-840-31	PANEL, BACK	

STEREO CASSETTE DECK
SONY[®]