









MODE SWITCH NO 2243





FIGURES IN CIRCLES CORRESPOND TO THESE NUMBERS.





FRONT OF RECORDER




CATHODE FOLLOWER - POWER OUTPUT SWITCH NO. 2253




EQUALIZATION SWITCH NO. 1996



STEREO SWITCH NO. 2234



DECK I, UNDERSIDE



DECK II, UNDERSIDE

FRONT OF RECORDER

TANDBERG TAPE RECORDER MODEL 5
DRAWING NO. 2240